

# AG-CX350 クリップ取込みガイド -SD,P2カードから- (Win) Premiere Pro CC Ver.14.0

Adobe Premiere Pro 2020 - C:\Users\slpalliance\Documents\Adobe\Premiere Pro\14.0\Untitled

File Edit Clip Sequence Markers Graphics View Window Help

Project: Untitled Media Browser Markers Audio Clip Mixer Libraries

Program: (no sequences) Source: (no clips)

Project: Untitled Media Browser

F: (A050)

Local Drives

C: (Windows )

F: (A050)

G: (A051)

CONTENTS

DCIM

PRIVATE

AVCHD

PANA\_GRP

001RFQA

Network Drives

Project: Untitled Media Browser

F: (A050)

Local Drives

C: (Windows )

F: (A050) P2 ①

G: (A051)

CONTENTS

DCIM

PRIVATE

AVCHD AVCHD ②

PANA\_GRP

001RFQA MOV ③

④ドラッグ & ドロップ

<P2 の場合>

①メディアブラウザにてP2カードを選択するとサムネイルが表示される

<AVCHDの場合>

②メディアブラウザにてSDカードを選択し、下層の「PRIVATE¥AVCHD」を選択するとサムネイルが表示される

<MOVの場合>

③メディアブラウザにてSDカードを選択し、下層の「PRIVATE¥PANA\_GRP¥サブフォルダー (例：001RFQAM)」を選択するとサムネイルが表示される

④クリップを選択し、プロジェクトにドロップする

⑤読み込み完了