

# AG-CX350 クリップ取込みガイド -SDカードから- (Win) DAVINCI RESOLVE STUDIO 15 Ver.15.2

The screenshot shows the DaVinci Resolve Studio 15.2 interface. The Media Storage panel on the left displays the file hierarchy: A004 (GA) (Usage: 0%) > CONTENTS > DCIM > PRIVATE > AVCHD > PANA\_GRP > 001RCQAM. A yellow arrow labeled 'ドラッグ' (Drag) points from a video file 'A004C001\_190404\_B90G.MOV' in the Media Storage panel to the timeline. A blue box contains the following instructions:

- ① メディアページにて、SDカードを選択
- ② MOVは[PANA\_GRP]フォルダを  
AVCHDは[AVCHD]フォルダを選択
- ③ MOVファイルやMTSファイルを表示  
する階層まで開く
- ④ クリップをドラッグ & ドロップでBinへ

A green box labeled 'ドロップ' (Drop) is at the bottom of the yellow arrow. The timeline at the bottom shows the clip being added. The bottom status bar indicates 'DaVinci Resolve 15' and 'Media' is selected.