

AG-CX350 クリップ取込みガイド -SD,P2カードから- (Win) Premiere Pro CC Ver.14.0

Adobe Premiere Pro 2020 - C:\Users\slpalliance\Documents\Adobe\Premiere Pro\14.0\Untitled

File Edit Clip Sequence Markers Graphics View Window Help

Project: Untitled Media Browser Markers Audio Clip Mixer Libraries

Program: (no sequences) Source: (no clips)

Project: Untitled Media Browser

F: (A050)

Local Drives

- C: (Windows)
- F: (A050)
- G: (A051)
 - CONTENTS
 - DCIM
 - PRIVATE
 - AVCHD
 - PANA_GRP
 - 001RFQA

Network Drives

Project: Untitled Media Browser

F: (A050)

Local Drives

- C: (Windows)
- F: (A050) **P2**
- G: (A051)
 - CONTENTS
 - DCIM
 - PRIVATE
 - AVCHD **AVCHD**
 - PANA_GRP
 - 001RFQA **MOV**

121KS9OQ 2020-01-21T09:44:00+09:00 2020-

122GN1PC 2020-01-21T09:44:06+09:00 2020-

123TD6KP 2020-01-21T09:44:10+09:00 2020-

ドラッグ & ドロップ

<P2 の場合>

①メディアブラウザにてP2カードを選択するとサムネイルが表示される

<AVCHDの場合>

②メディアブラウザにてSDカードを選択し、下層の「PRIVATE¥AVCHD」を選択するとサムネイルが表示される

<MOVの場合>

③メディアブラウザにてSDカードを選択し、下層の「PRIVATE¥PANA_GRP¥サブフォルダー (例：001RFQAM)」を選択するとサムネイルが表示される

④クリップを選択し、プロジェクトにドロップする

⑤読み込み完了